Service Manual

WorkCentre 5222 5225/5230

'Click' to download complete Manual

Tabloid
Black-and-white
Multifunction Printer



XEROX

WorkCentre 5222, 5225, 5230

Service Documentation

WorkCentre 5222, 5225, 5230 Service Documentation

701P48694

Revision (PDF)

June, 2008

Xerox Private Data

All service documentation is supplied to Xerox external customers for informational purposes only. Xerox service documentation is intended for use by certified, product-trained service personnel only. Xerox does not warrant or represent that it will notify or provide to such customer any future change to this documentation. Customer performed service of equipment, or modules, components, or parts of such equipment may affect whether Xerox is responsible to fix machine defects under the warranty offered by Xerox with respect to such equipment. You should consult the applicable warranty for its terms regarding customer or third-party provided service.

If the customer services such equipment, modules, components or parts thereof, the customer releases Xerox from any and all liability for the customer actions, and the customer agrees to indemnify, defend and hold xerox harmless from any third party claims which arise directly or indirectly for such service.

While Xerox has tried to make the documentation accurate, Xerox will have no liability arising out of any inaccuracies or omissions. Changes are periodically made to this document. Changes, technical inaccuracies, and typographical errors will be corrected in subsequent editions.

Prepared by:

Xerox Corporation

Global Knowledge and Language Services

800 Phillips Road, Bldg. 0218-01A

Webster, New York 14580-9791

USA

©2008 by Xerox Corporation. All rights reserved.

Copyright protection claimed includes all forms and matters of copyrightable material and information now allowed by statutory judicial law or hereinafter granted, including without limitation, material generated from the software programs which are displayed on the screen such as icons, screen displays, looks, etc.

Printed in the United States of America.

XEROX® and all Xerox product names mentioned in this publication are trademarks of XEROX CORPORATION. Other company trademarks are also acknowledged.

PANTONE is a registered trademark of Pantone, Inc.

Changes are periodically made to this document. Changes, technical inaccuracies, and typographic errors will be corrected in subsequent editions.

WARNING

This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions documentation, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to subpart B of part 15 of FCC rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference in which case the user, at his own expense, will be required to correct the interference.

Xerox Repair Manual.com

1 Service Call Procedures

Service Call Procedures 1-3
Initial Actions 1-3
Call Flow 1-4
Detailed Maintenance Activities (HFSI) 1-6
Cleaning Procedures 1-7
Final Actions 1-7

service-repairmanual.com

2 Status Indicator RAPs

002 HDD

002-500 UI Error RAP 2-15
002-770 Job Template Processing - HD Full RAP 2-15

003 IPS-ESS Communication

003-318 IIT Soft Failure RAP 2-17
003-319 IIT Video Driver Detection Failure RAP 2-17
003-320 IISS-ESS Communication Failure 1 RAP 2-18
003-321 IISS-ESS Communication Failure 2 RAP 2-18
003-322 IISS-ESS Communication Failure 3 RAP 2-19
003-323 IISS-ESS Communication Failure 4 RAP 2-19
003-324 IISS-ESS Communication Failure 5 RAP 2-20
003-325 IISS-ESS Communication Failure 6 RAP 2-20
003-326 IISS-ESS Communication Failure 7 RAP 2-21
003-327 IISS-ESS Communication Failure 8 RAP 2-21
003-328 IISS-ESS Communication Failure 9 RAP 2-22
003-329 IISS-ESS Communication Failure 10 RAP 2-22
003-330 IISS-ESS Communication Failure 11 RAP 2-23
003-331 IISS-ESS Communication Failure 12 RAP 2-23
003-332 IISS-ESS Communication Failure 13 RAP 2-24
003-333 IISS-ESS Communication Failure 14 RAP 2-24
003-334 IISS-ESS Communication Failure 15 RAP 2-25
003-335 IISS-ESS Communication Failure 16 RAP 2-25
003-336 IISS-ESS Communication Failure 17 RAP 2-26
003-337 IISS-ESS Communication Failure 18 RAP 2-26
003-338 IISS-ESS Communication Failure 19 RAP 2-27
003-339 IISS-ESS Communication Failure 20 RAP 2-27
003-340 IISS-ESS Communication Failure 21 RAP 2-28
003-341 IISS-ESS Communication Failure 22 RAP 2-28
003-342 IISS-ESS Communication Failure 23 RAP 2-29
003-343 IISS-ESS Communication Failure 24 RAP 2-29
003-702 Different magnification, for surface and back RAP 2-30
003-750 Book Duplex-Insufficient Docs RAP 2-30
003-751 Under PANTHER Capacity (Scan) RAP 2-31
003-752 Cannot scan over 600DPI RAP 2-31
003-753 Cannot scan over 300DPI RAP 2-32
003-754 S2X Recovery RAP 2-32
003-755 S2X Command Error RAP 2-33
003-756 Blank Originals RAP 2-33
003-757 Cannot scan over 400DPI RAP 2-34
003-760 Scan Settings Error RAP 2-34
003-761 Incorrect Paper Tray Size RAP 2-35
003-763 Adjustment Chart Not Found RAP 2-35
003-764 Image Overlay RAP 2-36
003-780 FAX Scan Compression Error RAP 2-36
003-795 AMS Limit Error RAP 2-37
003-930 300 DPI Scan RAP 2-37
003-931 400 DPI Scan RAP 2-38
003-932 600 DPI Scan RAP 2-38
003-933 300 DPI Scan RAP 2-39
003-934 400 DPI Scan RAP 2-39
003-935 600 DPI Scan RAP 2-40
003-940 Memory RAP 2-40
003-942 Document size Auto Detect Failure RAP 2-41
003-944 Image repeat count Failure RAP 2-41
003-946 Every direction difference (Copy APS) RAP 2-42
003-947 Return Documents counts error RAP 2-42
003-948 Return Documents mismatch RAP 2-43
003-952 Document Color Mismatch RAP 2-43
003-955 Documents size exchange error RAP 2-44
003-956 Documents size unknown error RAP 2-44
003-963 No APS object Tray RAP 2-45
003-965 ATS/APS No Paper (IIT Detect) RAP 2-45
003-966 ATS/APS No Destination (IIT) RAP 2-46
003-967 DADF APS No Destination RAP 2-46
003-968 Punch Position Error RAP 2-47
003-969 Punch Size Error RAP 2-47
003-970 FAX Line Memory Overflow RAP 2-48
003-971 Prevention Code Detect RAP 2-48
003-972 Maximum Stored Page Over Flow RAP 2-49
003-973 Every direction difference RAP 2-49
003-974 Next Original Specification RAP 2-50
003-976 FAX Line Memory Overflow (N up) RAP 2-50
003-977 Document Mismatch (Multiple Scan) RAP 2-51
003-978 Color Document Miss Match (Multi Scan) RAP 2-51
003-980 Staple position error RAP 2-52
003-981 Staple size error RAP 2-52
003-982 IIT HDD Access Error RAP 2-53

005 DADF

005-121 CVT Feed Sensor On JAM RAP 2-55
005-122 CVT Simplex/Side1 Pre-Registration On JAM RAP 2-56
005-123 CVT Simplex/Side1 Registration JAM RAP 2-57
005-125 CVT Registration Sensor Off JAM RAP 2-58
005-131 CVT Invert On JAM RAP 2-59
005-132 CVT Invert On JAM 2 RAP 2-60
005-134 CVT Invert Sensor Off JAM (Inverter) RAP 2-61
005-135 CVT Side2 Pre-Registration On JAM RAP 2-62
005-136 CVT Side2 Registration On JAM RAP 2-63
005-139 CVT Invert Sensor Off JAM RAP 2-64
005-145 CVT Registration Sensor Off JAM (Invert) RAP 2-65
005-146 CVT Pre Registration Sensor Off JAM RAP 2-66
005-147 CVT Pre Registration Sensor Off JAM (Invert) RAP 2-67
005-194 Size Mismatch Jam on Mix-size RAP 2-68
005-196 CVT Size Mismatch JAM (No Mix) RAP 2-69

www.servicemanual.com

005-197 Prohibit Combine Size JAM RAP 2-70
005-198 Too Short Size JAM RAP 2-71
005-199 Too Long Size JAM RAP 2-72
005-275 DADF ROM Download Error 2-73
005-275 DADF Error 2-73
005-280 DADF EPROM Failure RAP 2-74
005-284 DADF Auto Paper Selection Sensor Logic Failure RAP 2-74
005-285 DADF Nudger Lift Up Failure RAP 2-75
005-286 DADF Feed Out Sensor Failure RAP 2-76
005-305 CVT Feeder Cover Interlock Open (running) RAP 2-78
005-306 Tray Interlock Open RAP 2-78
005-309 CVT L/H Interlock Open RAP 2-79
005-500 Downloader Failure RAP 2-79
005-906 CVT Feed Sensor Static JAM RAP 2-80
005-907 CVT Pre-Registration Sensor Static JAM RAP 2-81
005-908 CVT Registration Sensor Static JAM RAP 2-82
005-909 DADF Lead Sensor Static Jam 2-82
005-910 DADF Out Sensor Static Jam 2-83
005-911 DADF Exit 1 Sensor Static Jam 2-83
005-912 DADF Exit 2 Sensor Static Jam 2-84
005-913 CVT Invert Sensor Static JAM RAP 2-84
005-914 DADF APS1, 2, 3, Sensor Static Jam 2-85
005-915 CVT APS No1 Sensor Static JAM RAP 2-85
005-916 CVT APS No2 Sensor Static JAM RAP 2-86
005-917 CVT APS No3 Sensor Static JAM RAP 2-87
005-918 CVT Invert Sensor Static Jam RAP 2-87
005-919 DADF Tray Lift Up Failure RAP 2-88
005-940 DADF No Original Failure RAP 2-88
005-941 DADF Not Enough Documents Failure RAP 2-89
005-942 Doc fault loading on DADF RAP 2-89

010 Fuser

010-313 Control (Center) Thermistor Failure RAP 2-91
010-314 Rear Thermistor Failure RAP 2-92
010-318 Hot-Sagging Recovery Failure RAP 2-93
010-320 Heat Roll Over Temperature Failure RAP 2-94
010-327 Fuser On Time Failure RAP 2-95
010-398 Fuser Lock Failure RAP 2-96
010-420 Fuser Near end of life RAP 2-96
010-421 Fuser end of life RAP 2-97

012 Integrated Finisher

012-132 (Integrated Finisher) Ent Sensor ON Jam 2-99
012-151 (Integrated Finisher) Compiler Exit Sensor OFF Jam 2-100
012-152 (Integrated Finisher) Compiler Exit Sensor ON Jam 2-101
012-161 (Integrated Finisher) Set Eject Jam 2-102
012-211 (Integrated Finisher) Stacker Tray Fail 2-103
012-221 (Integrated Finisher) Front Tamper Home Sensor ON Fail 2-105
012-223 (Integrated Finisher) Front Tamper Home Sensor OFF Fail 2-106
012-224 (Integrated Finisher) Rear Tamper Home Sensor OFF Fail 2-107
012-259 (Integrated Finisher) Eject Home Sensor ON Fail 2-108
012-263 (Integrated Finisher) Rear Tamper Home Sensor ON Fail 2-109
012-280 (Integrated Finisher) Eject Home Sensor OFF Fail 2-110
012-283 (Integrated Finisher) Set Clamp Home Sensor ON Fail 2-111
012-284 (Integrated Finisher) Set Clamp Home Sensor OFF Fail 2-112
012-291 (Integrated Finisher) Stapler Fail 2-113
012-301 (Integrated Finisher) Top Cover Interlock OPEN 2-114
012-302 (Integrated Finisher) Front Cover Interlock OPEN 2-115
012-903 (Integrated Finisher) Paper Remains at Compiler Exit Sensor 2-115
012-935 (Integrated Finisher) Paper Remains at Ent Sensor 2-116

012 LX Finisher

012-111 H-Transport Entrance Sensor Off JAM A RAP (LX) 2-117
012-112 H-Transport Entrance Sensor On JAM A RAP (LX) 2-118
012-126 H-Transport Entrance OFF JAM B RAP (LX) 2-119
012-131 H-Transport Entrance Sensor On JAM B RAP (LX) 2-120
012-132 H-Transport Entrance Sensor On JAM RAP (LX) 2-121
012-151 Compiler Exit Sensor Off JAM RAP (LX) 2-122
012-152 Compiler Exit Sensor On JAM RAP (LX) 2-123
012-161 Finisher Set Eject JAM RAP (LX) 2-124
012-211 Stacker Tray Failure RAP (LX) 2-125
012-212 Stacker Tray Upper Limit Failure RAP (LX) 2-126
012-213 Stacker Tray Lower Limit Failure RAP (LX) 2-127
012-221 Front Tamper Home Sensor On Failure RAP (LX) 2-128
012-223 Front Tamper Home Sensor Off Failure RAP (LX) 2-129
012-224 Rear Tamper Home Sensor Off Failure RAP (LX) 2-130
012-231 Punch Home Sensor ON Fail (LX) 2-131
012-243 Booklet Folder Home Sensor ON Fail (LX) 2-132
012-249 Booklet Front Stapler Fail (LX) 2-132
012-259 Eject Home Sensor ON Failure RAP (LX) 2-133
012-260 Eject Clamp Home Sensor ON Failure RAP (LX) 2-134
012-263 Rear Tamper Failure RAP (LX) 2-135
012-265 Booklet Folder Home Sensor OFF Fail (LX) 2-136
012-268 Booklet Rear Stapler Fail (LX) 2-136
012-269 Booklet Sub-CPU Communications Fail (LX) 2-137
012-282 Eject Clamp Home Sensor Off Failure RAP (LX) 2-137
012-283 Set Clamp Home Sensor On Failure RAP (LX) 2-138
012-284 Set Clamp Home Sensor Off Failure RAP (LX) 2-139
012-291 Stapler Failure RAP (LX) 2-141
012-295 Staple Move Sensor On Failure RAP (LX) 2-141
012-296 Staple Move Sensor Off Failure RAP (LX) 2-142
012-300 Eject Cover Open (LX) 2-143
012-302 Finisher Front Cover Open RAP (LX) 2-144
012-303 Finisher H-Transport Cover Open RAP (LX) 2-145
012-334 Download Mode Failure RAP (LX) 2-145
012-500 Download Failure RAP (LX) 2-146
012-700 Punch Dust Nearly Full RAP (LX) 2-146
012-901 Finisher H-Transport Entrance Sensor Static JAM RAP (LX) 2-147
012-903 Paper Remains at Compiler Exit Sensor RAP (LX) 2-148
012-905 Compile Tray No Paper Sensor JAM RAP (LX) 2-149
012-923 H-Transport Entrance SNR static JAM B RAP (LX) 2-150
012-935 Paper at Finisher Entrance Sensor (LX) 2-150
012-949 Punch Box Missing RAP (LX) 2-151

service repairmanual.com

013 LX-Booklet

013-210 Booklet Staple Move Home Sensor ON RAP (LX) 2-153
013-211 Booklet Staple Move Home Sensor OFF RAP (LX) 2-153
013-212 Booklet Staple Move Position Sensor On Fail RAP (LX) 2-154
013-213 Booklet Staple Move Position Sensor Off Fail RAP (LX) 2-155
013-220 Booklet Fold Detect Fail RAP (LX) 2-156
013-306 Booklet Safety Switches Open RAP (LX) 2-156
013-307 Booklet Cover Open RAP (LX) 2-157

016 FAX Service

016-210 Software Option (HDD Error) RAP 2-159
016-211 Software Option (System Memory Low) RAP 2-159
016-212 Software Option (Page Memory Low) RAP 2-160
016-213 Software Option (Printer PWB) RAP 2-160
016-214 Serial Number Mismatch RAP 2-161
016-215 Software Option RAP 2-161
016-216 Software Option RAP 2-162
016-217 Software Option RAP 2-162
016-218 PS KIT Not Exist for XDOD RAP 2-163
016-219 Software Option RAP 2-163
016-220 S2X Unrecoverable Error RAP 2-164
016-221 S2X Communication Error RAP 2-164
016-222 S2X self-diag error RAP 2-165
016-223 S2X SDRAM Error RAP 2-165
016-224 S2X PCI Reg Error RAP 2-166
016-225 S2X ROM CheckSum Error RAP 2-166
016-226 S2X IIT Connection Error RAP 2-167
016-227 S2X DDR Error RAP 2-167
016-228 S2X Image Processing Error RAP 2-168
016-240 S2X NVM CheckSum Fail RAP 2-168
016-310 ssmm Job Log Full RAP 2-169
016-311 Scanner Install RAP 2-169
016-315 IIT Interface RAP 2-170
016-316 Page Memory Not Detected RAP 2-170
016-317 Page Memory Error- Standard RAP 2-171
016-318 Page Memory Error- Option RAP 2-171
016-321 Fax Module Error RAP 2-172
016-322 JBA Account Full RAP 2-172
016-323 Scheduled Image Overwrite RAP 2-173
016-324 B Formatter Fatal Error RAP 2-173
016-330 ESS SystemMemory Fail-1 RAP 2-174
016-332 ESS SystemMemory Fail-3 RAP 2-174
016-335 ESS ProgramROM Fail-1 RAP 2-175
016-336 ESS ProgramROM Fail-2 RAP 2-175
016-337 ESS ProgramROM Fail-3 RAP 2-176
016-338 ESS FontROM Fail-1 RAP 2-176
016-339 ESS FontROM Fail-2 RAP 2-177
016-340 ESS FontROM Fail-3 RAP 2-177
016-341 ESS FontROM Fail-4 RAP 2-178
016-342 ESS RTC Failure RAP 2-178
016-345 ESS NV-Memory Failure RAP 2-179
016-347 ESS PageMemory Failure RAP 2-179
016-348 ESS PageMemory Failure-2 RAP 2-180
016-350 ESS SEEP-ROM Failure-1 RAP 2-180
016-351 ESS SEEP-ROM Failure-2 RAP 2-181
016-360 ESS UI Failure-1 RAP 2-181
016-362 ESS UI Failure-2 RAP 2-182
016-363 ESS LyraCard Failure RAP 2-182
016-364 ESS USB2.0 Host Failure RAP 2-183
016-365 ESS USB2.0 Device Failure RAP 2-183
016-366 ESS HDD Failure-1 RAP 2-184
016-367 ESS HDD Failure-2 RAP 2-184
016-368 ESS Torino Failure RAP 2-185
016-369 ESS S2X PWB Failure RAP 2-185
016-400 802.1x Authentication Failure RAP 2-186
016-401 802.1x EAP Type Not Supported RAP 2-186
016-402 802.1x Authentication Failure by Timing Out RAP 2-187
016-403 802.1x Certificate Failure RAP 2-187
016-404 802.1x Inside Failure RAP 2-188
016-450 SMB Host Name Duplicated RAP 2-188
016-453 Dynamic DNS - IPv6 NG RAP 2-189
016-454 DNS Dynamic Update RAP 2-189
016-455 SMTP Server Time-out RAP 2-190
016-456 SMTP time asynchronous RAP 2-190
016-500 DIMM RAP 2-191
016-501 S2X RAP 2-191
016-502 ROM Write RAP 2-192
016-503 SMTP Redirector RAP 2-192
016-504 Redirector POP Server RAP 2-193
016-505 Redirector POP Authentication RAP 2-193
016-513 XPS Error RAP 2-194
016-514 XPS Error RAP 2-194
016-515 XPS Short of Memory RAP 2-195
016-516 XPS PrintTicket Description Error RAP 2-195
016-517 PS Booklet Illegal Color Mode Change RAP 2-196
016-519 Device DV - Reached Limit RAP 2-196
016-522 LDAP RAP 2-197
016-523 LDAP RAP 2-197
016-524 LDAP RAP 2-198
016-525 LDAP RAP 2-198
016-526 LDAP RAP 2-199
016-527 LDAP RAP 2-199
016-533 LDAP RAP 2-200
016-534 LDAP RAP 2-200
016-539 LDAP RAP 2-201
016-574 Host Name Error RAP 2-201
016-575 DNS Server Error in FTP RAP 2-202
016-576 Server Connection Error in FTP RAP 2-202
016-577 FTP Service RAP 2-203
016-578 Login/Password Error RAP 2-203
016-579 Scanning Picture Error RAP 2-204
016-580 File Name Acquisition Failure RAP 2-204
016-581 File Name Suffix Limit Error RAP 2-205
016-582 File Creation Failure RAP 2-205

service-repairmanual.com

016-583 Lock Folder Creation Failure RAP 2-206
016-584 Folder Creation Failure RAP 2-206
016-585 File Delete Failure RAP 2-207
016-586 Lock Folder Delete Failure RAP 2-207
016-587 Folder Delete Failure RAP 2-208
016-588 Data Write-in Failure RAP 2-208
016-589 Data Read Failure RAP 2-209
016-590 Data Reading Failure RAP 2-209
016-591 Scan Filing Policy Injustice RAP 2-210
016-592 NEXTNAME.DAT file access error RAP 2-210
016-593 Internal Scan Error RAP 2-211
016-594 TYPE Command Failure RAP 2-211
016-595 Port Command Failure RAP 2-212
016-596 CDUP Command Failure RAP 2-212
016-597 Same Name File Exists RAP 2-213
016-600 Key Operator Authentication Locked RAP 2-213
016-601 Illegal Access Detection RAP 2-214
016-700 Password is Under Minimum RAP 2-214
016-701 ART EX Memory Expended RAP 2-215
016-702 Out of Page Buffer RAP 2-215
016-703 E-mail To Invalid Box RAP 2-216
016-704 Mailbox Full RAP 2-216
016-705 Secure Print RAP 2-217
016-706 Maximum Users Exceeded RAP 2-217
016-707 Sample Print RAP 2-218
016-708 HDD Full Annotation/Watermark RAP 2-218
016-709 ART EX Command RAP 2-219
016-710 Delayed Print RAP 2-219
016-711 E-mail Transmission Size Limit RAP 2-220
016-712 Panther Capacity (I-Formatted) RAP 2-220
016-713 Security Box Password RAP 2-221
016-714 Security Box Enable RAP 2-221
016-716 TIFF Data Overflow RAP 2-222
016-717 Fax/iFax Send RAP 2-222
016-718 PCL6 Memory RAP 2-223
016-719 Out of PCL Memory RAP 2-223
016-720 PCL Command RAP 2-224
016-722 Staple Position RAP 2-224
016-723 Punch Position Error RAP 2-225
016-724 Staple Position RAP 2-225
016-725 B-Formatter Image RAP 2-226
016-727 Printer Request 2-226
016-728 TIFF Data Unsupported RAP 2-227
016-729 TIFF Data Size RAP 2-227
016-730 ART Command Unsupported RAP 2-228
016-731 TIFF Data Invalid RAP 2-228
016-732 Form Not Registered RAP 2-229
016-733 Destination Address RAP 2-229
016-734 Transmission Report RAP 2-230
016-735 Updating Job Template RAP 2-230
016-736 Remote Directory Lock RAP 2-231
016-737 Remote Directory Removal RAP 2-231
016-738 PS Booklet Output Size Illegal RAP 2-232
016-739 Document and Output Mismatch RAP 2-232
016-740 Output Tray Incorrect RAP 2-233
016-741 Cannot Shift to Download Mode Failure RAP 2-233
016-742 Download Data ProductID Error RAP 2-234
016-743 Download Data Model Mismatch RAP 2-234
016-744 Download Data CheckSum Error RAP 2-235
016-745 XPJL Soft Failure RAP 2-235
016-746 Unsupported PDF File RAP 2-236
016-747 Insufficient Memory 2-236
016-748 HDD Full RAP 2-237
016-749 Post Script Font RAP 2-237
016-750 Print Job RAP 2-238
016-751 PDF RAP 2-238
016-752 PDF Memory Limit RAP 2-239
016-753 PDF Password Mismatch RAP 2-239
016-755 PDF Print Prohibited RAP 2-240
016-756 Auditron - Prohibit Service RAP 2-240
016-757 Auditron - Invalid User RAP 2-241
016-758 Auditron - Disabled Function RAP 2-241
016-759 Auditron - Reached Limit RAP 2-242
016-760 PostScript Decompose RAP 2-242
016-761 FIFO Empty RAP 2-243
016-762 Print Language RAP 2-243
016-763 POP Server is not found RAP 2-244
016-764 SMTP Server Connection RAP 2-244
016-765 SMTP Server HDD Full RAP 2-245
016-766 SMTP Server File System RAP 2-245
016-767 Invalid E-mail Address RAP 2-246
016-768 Invalid Sender Address RAP 2-246
016-769 SMTP Server Unsupported DSN RAP 2-247
016-770 FAX Function Cancelled RAP 2-247
016-771 JBIG Parameter RAP 2-248
016-772 JBIG Parameter RAP 2-248
016-773 JBIG Parameter RAP 2-249
016-774 JBIG Parameter RAP 2-249
016-775 JBIG Parameter RAP 2-250
016-776 JBIG Parameter RAP 2-250
016-777 JBIG Parameter RAP 2-251
016-778 JBIG Parameter RAP 2-251
016-779 Scanned Image Conversion Error RAP 2-252
016-780 Attached Document TIFF RAP 2-252
016-781 Scan Server Connect Error RAP 2-253
016-782 Scan Server Login Error RAP 2-254
016-783 Invalid Server Path RAP 2-255
016-784 Server Write Error RAP 2-256
016-785 Server HD Full RAP 2-256
016-786 HD Full-Scan Write Error RAP 2-257
016-787 Invalid Server IP ADD RAP 2-257
016-788 Retrieve to Browser RAP 2-258
016-789 HD Full - Job Memory RAP 2-258
016-791 File Retrieve RAP 2-259

service-repairmanual.com

016-792 Specified Job RAP 2-259
016-793 MF I/O HD Full RAP 2-260
016-799 PLW Print Instruction RAP 2-260
016-981 HDD access error RAP 2-261
016-982 HDD access error 2 RAP 2-261
016-983 Log Image Storage Area on Disk Full RAP 2-262
016-985 Data size overflow (Scan to E-mail) RAP 2-262

018 LDAP

018-400 IPSEC Error (Configuration Mismatch) RAP 2-263
018-500 CA Message Receiver Boot Error (S_cert lost) RAP 2-263
018-501 CA Server Connection Error RAP 2-264
018-502 Login Failure in SMB RAP 2-264
018-503 CA Message Receiver Timeout RAP 2-265
018-504 CA SessionID Mismatch RAP 2-265
018-505 SMB-DOS protocol error RAP 2-266
018-506 CA FieldID Mismatch RAP 2-266
018-507 CA Credential Error RAP 2-267
018-508 CA Server Fatal Error RAP 2-267
018-509 Template Parameter Conflict RAP 2-268
018-509 Template Parameter Conflict RAP 2-268
018-510 Host name solution error in BMLinkS RAP 2-269
018-511 DNS server un-sets up in BMLinkS RAP 2-269
018-512 Service Connect error in BMLinkS RAP 2-270
018-513 BMLinkS Service Not Found RAP 2-270
018-514 BMLinkS Access-Right-Violation RAP 2-271
018-515 BMLinkS Storage-Access-Error RAP 2-271
018-516 BMLinkS unsupported-attribute RAP 2-272
018-517 BMLinkS Storage-Full RAP 2-272
018-518 BMLinkS Operation-Not-Available RAP 2-273
018-519 BMLinkS unknown-error RAP 2-273
018-520 Internal error in BMLinkS Scan RAP 2-274
018-521 Request Send Failure in BMLinkS RAP 2-274
018-522 Response receive failure in BMLinkS RAP 2-275
018-523 Image Send Failure in BMLinkS RAP 2-275
018-524 Invalid Device Network Setting RAP 2-276
018-525 HDD Full or HDD Access Error RAP 2-276
018-526 Rejected to be Refresh RAP 2-277
018-527 JT Monitor Internal Error RAP 2-277
018-528 Soap Request Error RAP 2-278
018-529 Duplicate Scan Request RAP 2-278
018-530 Authentication Error RAP 2-279
018-531 Failed to Create a New Job RAP 2-279
018-532 Too Many Jobs to Create a New Job RAP 2-280
018-543 Shared name error in SMB server RAP 2-280
018-547 Number restriction over of SMB scan users RAP 2-281
018-596 LDAP Protocol Error 596 RAP 2-281
018-701 LDAP RAP 2-282
018-702 LDAP RAP 2-282
018-703 LDAP RAP 2-283
018-704 LDAP RAP 2-283
018-705 LDAP RAP 2-284
018-706 LDAP RAP 2-284
018-707 LDAP RAP 2-285
018-708 LDAP RAP 2-285
018-710 LDAP RAP 2-286
018-711 LDAP RAP 2-286
018-712 LDAP RAP 2-287
018-713 LDAP RAP 2-287
018-714 LDAP RAP 2-288
018-716 LDAP RAP 2-288
018-717 LDAP RAP 2-289
018-718 LDAP RAP 2-289
018-719 LDAP RAP 2-290
018-720 LDAP RAP 2-290
018-721 LDAP RAP 2-291
018-732 LDAP RAP 2-291
018-733 LDAP RAP 2-292
018-734 LDAP RAP 2-292
018-735 LDAP RAP 2-293
018-736 LDAP RAP 2-293
018-748 LDAP RAP 2-294
018-749 LDAP RAP 2-294
018-750 LDAP RAP 2-295
018-751 LDAP RAP 2-295
018-752 LDAP RAP 2-296
018-753 LDAP RAP 2-296
018-754 LDAP RAP 2-297
018-764 LDAP RAP 2-297
018-765 LDAP RAP 2-298
018-766 LDAP RAP 2-298
018-767 LDAP RAP 2-299
018-768 LDAP RAP 2-299
018-769 LDAP RAP 2-300
018-770 LDAP RAP 2-300
018-771 LDAP RAP 2-301
018-780 LDAP RAP 2-301
018-781 LDAP RAP 2-302
018-782 LDAP RAP 2-302
018-783 LDAP RAP 2-303
018-784 LDAP RAP 2-303
018-785 LDAP RAP 2-304
018-786 LDAP RAP 2-304
018-787 LDAP RAP 2-305
018-788 LDAP RAP 2-305
018-789 LDAP RAP 2-306
018-790 LDAP RAP 2-306
018-791 LDAP RAP 2-307
018-792 LDAP RAP 2-307
018-793 LDAP RAP 2-308
018-794 LDAP RAP 2-308
018-795 LDAP RAP 2-309
018-796 LDAP RAP 2-309
018-797 LDAP RAP 2-310

Service repairmanual.com

021 FAX

021-947 Subtractive Accessory Disable (Scan) RAP 2-311
021-948 Subtractive Accessory Disable (Print) RAP 2-311
021-949 Subtractive Accessory Disable RAP 2-312

024 IOT-ESS Communication a-finisher

024-916 (A-Finisher) Mix Stack Full 2-313
024-917 (A-Finisher) Stacker Tray Staple Set Over Count 2-314
024-928 (A-Finisher) Scratch Sheet Compile 2-316
024-930 (A-Finisher) Stacker Tray Full Stack 2-316
024-976 (A-Finisher) Staple NG 2-318
024-977 (A-Finisher) Stapler Feed Ready Fail 2-319
024-979 (A-Finisher) Stapler Near Empty 2-319
024-980 (A-Finisher) Stacker Tray Full Stack 2-320
024-982 (A-Finisher) Stacker Lower Safety Warning 2-321

024 IOT-ESS Communication

024-340 IOT-ESS Communication Failure 1 RAP 2-323
024-341 IOT-ESS Communication Failure 2 RAP 2-323
024-342 IOT-ESS Communication Failure 3 RAP 2-324
024-343 IOT-ESS Communication Failure 4 RAP 2-324
024-345 IOT-ESS Communication Failure 5 RAP 2-325
024-346 IOT-ESS Communication Failure 6 RAP 2-325
024-347 IOT-ESS Communication Failure 7 RAP 2-326
024-348 IOT-ESS Communication Failure 8 RAP 2-326
024-349 IOT-ESS Communication Failure 9 RAP 2-327
024-350 IOT-ESS Communication Failure 10 RAP 2-327
024-351 IOT-ESS Communication Failure 11 RAP 2-328
024-354 IOT-ESS Communication Failure 14 RAP 2-328
024-356 IOT-ESS Communication Failure 16 RAP 2-329
024-362 Page Sync Illegal Start RAP 2-329
024-363 Page Sync Illegal Stop RAP 2-330
024-364 DMA Transfer RAP 2-330
024-367 Decompress Other Failure RAP 2-331
024-368 PCI Error RAP 2-331
024-370 Marker Code Detection Failure RAP 2-332
024-371 IOT-ESS Communication Failure 21 RAP 2-332
024-372 IOT-ESS Communication Failure 22 RAP 2-333
024-373 IOT-ESS Communication Failure 23 RAP 2-333
024-375 IOT-ESS Communication Failure 24 RAP 2-334
024-600 Billing Master Counter RAP 2-334
024-601 Billing Backup Counter 1 RAP 2-335
024-602 Billing Backup Counter 2 RAP 2-335
024-603 Software Key Master Counter RAP 2-336
024-604 Software Key Backup Counter 1 RAP 2-336
024-605 Software Key Backup Counter 2 RAP 2-337
024-700 Shortage Memory Capacity, or no Hard Disk RAP 2-337
024-742 Output Paper for Booklet, Over Counts RAP 2-338
024-746 Print Request Failure-Paper RAP 2-338
024-747 Print Instruction Failure RAP 2-339
024-748 Bates Numbering Digit Over RAP 2-339
024-775 Output paper for Booklet, over counts 2 RAP 2-340
024-910 Tray 1 size mismatch RAP 2-340
024-911 Tray 2 size mismatch RAP 2-341
024-912 Tray 3 size mismatch RAP 2-342
024-913 Tray 4 size mismatch RAP 2-343
024-914 Tray 6 size mismatch RAP 2-344
024-915 Tray 7 size mismatch RAP 2-345
024-916 Mix Full Stack RAP 2-346
024-917 Stacker Tray Staple Set Over Count RAP 2-347
024-919 Face UP Tray Close RAP 2-348
024-920 Face Down Tray 1 Paper Full RAP 2-348
024-921 Face Up Tray 1 Paper Full 2-349
024-922 Face Down Tray 2 Paper Full 2-349
024-926 Punch Dust Box Miss Set 2-350
024-928 Scratch Sheet Compile 2-350
024-930 Stacker Tray Full (Large Size Full) 2-351
024-934 Paper kind Mismatch 2-351
024-939 OHP Kind Mismatch 2-352
024-946 Tray 1 Out Of Place RAP 2-352
024-947 Tray 2 Out Of Place RAP 2-353
024-948 Tray 3 Out Of Place RAP 2-353
024-949 Tray 4 Out Of Place RAP 2-354
024-950 Tray 1 Empty RAP 2-354
024-951 Tray 2 Empty RAP 2-355
024-952 Tray 3 Empty RAP 2-355
024-953 Tray 4 Empty RAP 2-356
024-954 MPT Empty RAP 2-356
024-955 Tray 6 Empty 2-357
024-958 MPT Size Failure RAP 2-357
024-959 Tray 1 size mismatch RAP 2-358
024-960 Tray 2 size mismatch RAP 2-358
024-961 Tray 3 size mismatch RAP 2-359
024-962 Tray 4 size mismatch RAP 2-359
024-965 ATS/APS No Paper (IOT detect) RAP 2-360
024-966 ATS/APS No Destination Error RAP 2-361
024-967 Different width Mix Paper detect (Stapler job) RAP 2-361
024-968 Stapler / Punch Batting 2-362
024-969 Different Width Mix Punch 2-362
024-970 Tray 6 Out Of Place 2-363
024-972 Tray 6 Size Mismatch 2-363
024-975 Copy Booklet Sheets Counts Over 2-364
024-976 Finisher Staple Status Failed RAP 2-364
024-977 Stapler Feed Ready Failure RAP 2-365
024-978 Booklet Stapler Fault 2-365
024-979 Stapler Near Empty RAP 2-366
024-980 Finisher Stacker Tray Full RAP 2-366
024-981 Finisher Top Tray Full 2-367
024-982 Stacker Lower Safety warning RAP 2-368
024-985 MPT Feed Failure RAP 2-369
024-989 Booklet Low Staple 2-369

024 IOT-ESS Communication sb-finisher

024-916 Mix Full Stack RAP 2-371

service-repairmanual.com

024-917 Stacker Tray Staple Set Over Count RAP 2-372
024-928 Scratch Sheet Compile RAP 2-372
024-976 Finisher Staple Status Failed RAP 2-373
024-977 Stapler Feed Ready Failure RAP 2-373
024-978 Booklet Front/Rear Stapler Fail 2-374
024-979 Stapler Near Empty RAP 2-375
024-980 Finisher Stacker Tray Full RAP 2-375
024-982 Stacker Lower Safety warning RAP 2-376
024-984 Booklet Low Staple F 2-377
024-989 Booklet Low Staple R 2-378

026 Address Book

026-700 LDAP Protocol Max Error RAP 2-379
026-702 Address Book Directory Service Overflow RAP 2-379

027 MAIL

027-400 Net Off Line RAP 2-381
027-442 Duplicate IP Address RAP 2-381
027-443 DNS Renewal Failure of Dynamic RAP 2-382
027-444 Duplicate IP Address RAP 2-382
027-445 Illegal IP Address RAP 2-383
027-446 Duplicate IP Address RAP 2-383
027-447 Duplicate IP Address RAP 2-384
027-452 Duplicate IP Address RAP 2-384
027-500 SMTP Server Mail I/O RAP 2-385
027-501 POP Server RAP 2-385
027-502 POP Authentication RAP 2-386
027-503 POP server communication timeout RAP 2-386
027-504 Invalid Response Reception from SMTP Server RAP 2-387
027-513 SMB Scan Client RAP 2-387
027-514 Host Name Solution Error RAP 2-388
027-515 DNS Server Error in SMB RAP 2-388
027-516 Server Connection Error in SMB RAP 2-389
027-518 Login/Password Error RAP 2-389
027-519 Scanning Picture Error RAP 2-390
027-520 File Name Acquisition Failure RAP 2-390
027-521 File Name Suffix Limit Error RAP 2-391
027-522 File Creation Failure RAP 2-391
027-523 Lock Folder Creation Failure RAP 2-392
027-524 Folder Creation Failure RAP 2-392
027-525 File Delete Failure RAP 2-393
027-526 Lock Folder Delete Failure RAP 2-393
027-527 Folder Delete Failure RAP 2-394
027-528 Data Write-in Failure RAP 2-394
027-529 Data Read Failure RAP 2-395
027-530 Data Reading Failure RAP 2-395
027-531 Scan Filing Policy Injustice RAP 2-396
027-532 NEXTNAME.DAT file access error RAP 2-396
027-533 Internal Scan Error RAP 2-397
027-543 Server Name Specification Error RAP 2-397
027-547 SMB Protocol error 4-007 RAP 2-398
027-548 SMB Protocol error 4-008 RAP 2-398
027-549 SMB Protocol error 4-009 RAP 2-399
027-564 SMB Protocol error 4-024 RAP 2-399
027-565 SMB Protocol error 4-025 RAP 2-400
027-566 SMB Protocol error 4-026 RAP 2-400
027-569 SMB (TCP/IP) is not Started RAP 2-401
027-572 SMB Protocol error 4-032 RAP 2-401
027-573 SMB Protocol error 4-033 RAP 2-402
027-574 SMB Protocol error 4-034 RAP 2-402
027-576 SMB Protocol error 4-036 RAP 2-403
027-578 SMB Protocol error 4-038 RAP 2-403
027-584 SMB Protocol error 4-044 RAP 2-404
027-585 SMB Protocol error 4-045 RAP 2-404
027-586 SMB Protocol error 4-046 RAP 2-405
027-587 SMB Protocol error 4-047 RAP 2-405
027-588 SMB Protocol error 4-048 RAP 2-406
027-589 SMB Protocol error 4-049 RAP 2-406
027-590 SMB Protocol error 4-050 RAP 2-407
027-591 SMB Protocol error 4-051 RAP 2-407
027-599 SMB Protocol error 4-other codes RAP 2-408
027-702 Certificate for Recipients, was not Found RAP 2-408
027-703 Certificate for Recipients, has Expired RAP 2-409
027-704 Certificate for Recipients, was Untrusted RAP 2-409
027-705 Certificate for Recipients, was revoked RAP 2-410
027-706 Certificate RAP 2-410
027-707 Certificate Expired RAP 2-411
027-708 Certificate Valid RAP 2-411
027-709 Certificate Revoked RAP 2-412
027-710 Invalid S/MIME Mail RAP 2-412
027-711 S/MIME Mail Certificate RAP 2-413
027-712 S/MIME Mail Certificate RAP 2-413
027-713 S/MIME Mail Altered RAP 2-414
027-714 S/MIME Mail Invalid RAP 2-414
027-715 S/MIME Mail Certificate Registration RAP 2-415
027-716 Email Signature RAP 2-415
027-730 SMTP Mail Division Error RAP 2-416
027-737 Template Server Read RAP 2-416
027-739 Invalid Template Server Path RAP 2-417
027-740 Template Server Login RAP 2-417
027-741 Template Server Connect RAP 2-418
027-742 HDD File System RAP 2-418
027-743 Template Server Install RAP 2-419
027-744 Template Address RAP 2-419
027-745 Template Address Server RAP 2-420
027-750 Fax Document Inhibited RAP 2-420
027-751 Job Template Analysis RAP 2-421
027-752 Required User Entry Not Entered RAP 2-421
027-753 Job Flow Service Disabled RAP 2-422
027-754 Job Flow Service File Signature Mismatch RAP 2-422
027-760 XJT Command Fail RAP 2-423
027-761 Web Print Time Out RAP 2-423
027-762 Illegal Web Print Job Ticket RAP 2-424
027-772 SMTP Server Error (HELO) RAP 2-424

service-repairmanuals.com

027-773 SMTP Server Communication Timeout RAP 2-425
027-774 Address Inaccurate Character RAP 2-425
027-775 Too Many SMTP Address RAP 2-426
027-776 SMTP Server Error (EHLO) RAP 2-426
027-777 SMTP Server Un-Supports SMTP-AUTH RAP 2-427
027-778 No Mode Specified by SMTP-AUTH RAP 2-427
027-779 It attestation-fails by SMTP-AUTH RAP 2-428
027-796 E-mail Not Printed RAP 2-428
027-797 Invalid Output Destination RAP 2-429

033 FAX Control

033-363 Fax Control RAP 2-431
033-710 Fax Control RAP 2-431
033-712 Fax Control RAP 2-432
033-713 Fax Control RAP 2-432
033-715 Fax Control RAP 2-433
033-716 Fax Control RAP 2-433
033-717 Fax Control RAP 2-434
033-718 Fax Control RAP 2-434
033-719 Fax Control RAP 2-435
033-721 Fax Control RAP 2-435
033-722 Fax Control RAP 2-436
033-724 Fax Control RAP 2-436
033-725 Fax Control RAP 2-437
033-726 Fax Control RAP 2-437
033-727 Fax Control RAP 2-438
033-728 Fax Control RAP 2-438
033-731 Fax Control RAP 2-439
033-733 Fax Control RAP 2-439
033-734 Fax Control RAP 2-440
033-735 Fax Control RAP 2-440
033-736 Fax Control RAP 2-441
033-737 Fax Control RAP 2-441
033-738 Fax Control RAP 2-442
033-740 Fax Control RAP 2-442
033-741 Fax Control RAP 2-443
033-742 Fax Control RAP 2-443
033-743 Fax Control RAP 2-444
033-744 Fax Control RAP 2-444
033-745 Fax Control RAP 2-445
033-746 Fax Control RAP 2-445
033-747 Fax Control RAP 2-446
033-749 Fax Control RAP 2-446
033-750 Fax Control RAP 2-447
033-751 Activity Report suspended RAP 2-447
033-755 Fax printing is canceled Fax RAP 2-448

034 FAX Communication

034-211 Fax Communication RAP 2-449
034-212 Fax Communication RAP 2-449
034-500 Fax Communication RAP 2-450
034-501 Fax Communication RAP 2-450
034-505 Fax Communication RAP 2-451
034-506 Fax Communication RAP 2-451
034-507 Fax Communication RAP 2-452
034-508 Fax Communication RAP 2-452
034-509 Fax Communication RAP 2-453
034-510 Fax Communication RAP 2-453
034-511 Fax Communication RAP 2-454
034-512 Fax Communication RAP 2-454
034-513 Fax Communication RAP 2-455
034-514 Fax Communication RAP 2-455
034-515 Fax Communication RAP 2-456
034-519 Fax Communication RAP 2-456
034-520 Fax Communication RAP 2-457
034-521 Internal I/F Error RAP 2-457
034-522 Fax Communication RAP 2-458
034-523 Fax Communication RAP 2-458
034-527 Dial Control Error RAP 2-459
034-528 Fax Communication RAP 2-459
034-529 Fax Communication RAP 2-460
034-530 Fax Communication RAP 2-460
034-550 Write to FaxCard-ROM error detection RAP 2-461
034-700 GCPLock-G3DicepBusy-CodecHang RAP 2-461
034-701 Software Reset RAP 2-462
034-789 Fax Communication RAP 2-462
034-790 Fax Communication Channel 0 RAP 2-463
034-791 Fax Communication Channel 1 RAP 2-463
034-792 Fax Communication Channel 2 RAP 2-464
034-793 Fax Communication Channel 3 RAP 2-464
034-794 Fax Communication Channel 4 RAP 2-465
034-795 Fax Communication Channel 5 RAP 2-465
034-796 Fax Communication Channel RAP 2-466
034-797 Communication Parameter Error RAP 2-466
034-798 Data Parameter Error RAP 2-467
034-799 Auto Dial Without Dial Data RAP 2-467

035 FAX Network

035-550 Write to FaxG3-ROM error detection RAP 2-469
035-700 Fax Protocol RAP 2-469
035-701 Fax Protocol RAP 2-470
035-702 Fax Protocol RAP 2-470
035-703 Fax Protocol RAP 2-471
035-704 Fax Protocol RAP 2-471
035-705 Fax Protocol RAP 2-472
035-706 Fax Protocol RAP 2-472
035-707 Fax Protocol RAP 2-473
035-708 Fax Protocol RAP 2-473
035-709 Fax Protocol RAP 2-474
035-710 Fax Protocol RAP 2-474
035-711 Fax Protocol RAP 2-475
035-712 Fax Protocol RAP 2-475
035-713 Fax Protocol RAP 2-476
035-714 Fax Protocol RAP 2-476

service-repairmanual.com

035-715 Fax Protocol RAP 2-477
035-716 Fax Protocol RAP 2-477
035-717 Fax Protocol RAP 2-478
035-718 Fax Protocol RAP 2-478
035-719 Fax Protocol RAP 2-479
035-720 Fax Protocol RAP 2-479
035-721 Fax Protocol RAP 2-480
035-722 Fax Protocol RAP 2-480
035-723 Fax Protocol RAP 2-481
035-724 Fax Protocol RAP 2-481
035-725 Fax Protocol RAP 2-482
035-726 Fax Protocol RAP 2-482
035-727 Fax Protocol RAP 2-483
035-728 Fax Protocol RAP 2-483
035-729 Fax Protocol RAP 2-484
035-730 Fax Protocol RAP 2-484
035-731 Fax Protocol RAP 2-485
035-732 Fax Protocol RAP 2-485
035-733 Fax Protocol RAP 2-486
035-734 Fax Protocol RAP 2-486
035-735 Fax Protocol RAP 2-487
035-736 Fax Protocol RAP 2-487
035-737 Fax Protocol RAP 2-488
035-738 Fax Protocol RAP 2-488
035-739 Fax Protocol RAP 2-489
035-740 Fax Protocol RAP 2-489
035-741 Fax Protocol RAP 2-490
035-742 Fax Protocol RAP 2-490
035-743 Fax Protocol RAP 2-491
035-744 Fax Protocol RAP 2-491
035-745 Fax Protocol RAP 2-492
035-746 Fax Protocol RAP 2-492
035-747 Fax Protocol RAP 2-493
035-748 Fax Protocol RAP 2-493
035-749 Fax Protocol RAP 2-494
035-750 Fax Protocol RAP 2-494
035-751 Fax Protocol RAP 2-495
035-752 Fax Protocol RAP 2-495
035-753 Fax Memory Full RAP 2-496
035-754 File Management Memory Full RAP 2-496
035-755 File Add Page Error RAP 2-497
035-756 Cannot Add Page RAP 2-497
035-757 No Receive Page RAP 2-498
035-758 No Specified File or Page RAP 2-498
035-759 No Specified Job RAP 2-499
035-760 No Specified Job RAP 2-499
035-761 File Processing Error RAP 2-500

041 NVM

041-340 MCU PWB Data RAP 2-501
041-500 2-501
041-501 2-502

042 Drives

042-323 Drum K Motor Drive Failure RAP 2-503
042-325 Main Motor Failure RAP 2-503

047 Communication

047-211 OCT 1 RAP 2-505
047-212 OCT 2 RAP 2-506
047-213 Different Finisher Detected RAP 2-507
047-214 MCU Duplex Module RAP 2-507
047-215 MCU Exit Communication Error RAP 2-508
047-216 MCU Finisher Communication RAP 2-508
047-217 MCU HCF Communication RAP 2-509

061 ROS

061-315 Start Of Scan RAP 2-511
061-321 ROS Motor RAP 2-511
061-333 ROS Fan Defect RAP 2-512

062 IIT

062-211 IIT/IPS PWB EEPROM RAP 2-513
062-277 IIT/IPS PWB DADF PWB Communication RAP 2-513
062-300 Platen Interlock Open RAP 2-514
062-310 IIT/IPS PWB Controller Communication RAP 2-514
062-311 IIT/IPS Software RAP 2-515
062-345 IIT/IPS Subsystem RAP 2-515
062-357 CCD Fan Failure RAP 2-516
062-360 Carriage Position RAP 2-516
062-371 Lamp Illumination RAP 2-517
062-380 Platen AGC CH1 RAP 2-518
062-386 Platen AOC CH1 RAP 2-518
062-389 Carriage Over Run RAP 2-519
062-392 IIT/IPS PWB Memory Failure-1 RAP 2-519
062-393 IIT/IPS PWB RAM RAP 2-520
062-500 IISS ROM RAP 2-520
062-790 Prohibited Document Detection RAP 2-521

071 Tray 1

071-105 Tray 1 Registration Sensor On JAM RAP 2-523
071-210 Tray 1 Lift Up Failure RAP 2-524
071-211 Tray 1 Broken RAP 2-525
071-940 Tray 1 Lift Up RAP 2-525

072 Tray 2

072-101 Tray 2 MisFeed JAM RAP 2-527
072-105 Tray 2 Registration Sensor On JAM RAP 2-528
072-210 Tray 2 Lift Up Failure RAP 2-529
072-211 Tray 2 Broken RAP 2-530
071-940 Tray 2 Lift Up RAP 2-530

073 Tray 3

073-101 Tray 3 Miss Feed JAM RAP 2-531
073-102 Tray 2 Feed Out Sensor On JAM (Tray 3 Feed) RAP 2-532
073-105 Tray 3 Registration Sensor On JAM RAP 2-533

www.xerox-repairmanual.com

073-210 Tray 3 Lift Up Failure RAP 2-534
073-211 Tray 3 Broken RAP 2-535
071-940 Tray 3 Lift Up RAP 2-535

074 Tray 4

074-101 Tray 4 Miss Feed JAM RAP 2-537
074-102 Tray 2 Feed Out Sensor On JAM (Tray 4 Feed) RAP 2-538
074-103 Tray 3 Feed Out Sensor On JAM (Tray 4 Feed) RAP 2-539
074-105 Tray 4 Registration Sensor On JAM RAP 2-540
074-210 Tray 4 Lift Up Failure RAP 2-541
074-211 Tray 4 Broken RAP 2-542
071-940 Tray 4 Lift Up RAP 2-542

075 MPT

075-135 MPT Registration Sensor On JAM RAP 2-543

077 Jam and Cover Open

077-101 Registration Sensor Off JAM RAP 2-545
077-103 Fuser Exit Sensor Off JAM RAP 2-546
077-104 Exit Sensor off (too short) JAM RAP 2-547
077-106 Fuser Exit Sensor On JAM RAP 2-548
077-109 IOT Exit Sensor ON JAM Straight RAP 2-549
077-113 IOT Exit Sensor OFF JAM Straight RAP 2-550
077-114 Exit 2 Sensor Static JAM RAP 2-550
077-129 Registration Sensor On JAM (Duplex Feed/Stop Case) RAP 2-551
077-130 Duplex Out Sensor On JAM RAP 2-552
077-131 Duplex Wait Sensor On JAM RAP 2-553
077-211 Detected different Type Tray Module RAP 2-554
077-300 IOT Front Cover Open RAP 2-554
077-301 Left Hand Interlock Open RAP 2-555
077-305 Tray Module Left Hand Cover Interlock Open RAP 2-556
077-307 DUP Cover Open RAP 2-556
077-308 Left Hand HIGH Interlock Open RAP 2-557
077-309 Left Hand Low Interlock Open RAP 2-557
077-310 Controller Failed to send image RAP 2-558
077-329 Main Motor Stop Error RAP 2-558

078 Controller

078-101 HCF to Feed Out Sensor Fault RAP 2-559
078-102 HCF to Registration Sensor Fault RAP 2-559
078-104 HCF Feed Out Sensor Fault RAP 2-560
078-210 HCF to Tray 1 Lift RAP 2-560
078-212 NVM Read/Write Failure RAP 2-561
078-300 HCF Top Cover Interlock Open RAP 2-562
078-301 HCF Docking interlock Open RAP 2-562
078-500 Write to HCF-ROM error detection (During DLD method) RAP 2-563
078-900 HCF Feed Out Sensor Static Jam RAP 2-563
078-940 HCF Paper Misfeed RAP 2-564
078-941 HCF Paper Tray Size Mismatch RAP 2-564
078-945 TTM Tray 3 Lift RAP 2-565
078-946 TTM Tray 4 Lift RAP 2-566

081 Fax Destination

081-799 Registered Destination RAP 2-567

091 Drum

091-402 Drum Life Over RAP 2-569
091-441 Drum Life Near End of Life RAP 2-569
091-910 Waste Toner Bottle Position RAP 2-570
091-911 Waste Toner Full RAP 2-570
091-912 Xerographics Drum Module Installation RAP 2-571
091-913 Drum Cartridge End of Life RAP 2-571
091-914 Xero CRUM Comm RAP 2-572
091-915 Xero CRUM Data RAP 2-572
091-916 Xero CRUM Match RAP 2-573

092 Process Control

092-661 Temperature Sensor RAP 2-575
092-662 Humidity Sensor RAP 2-575

093 Toner Supply

093-400 Black Toner Near Empty 2-577
093-406 Black Toner Pre-Near Empty 2-577
093-912 ..... Black
Toner Empty 2-578
093-924 Toner K Crum Communication Failure 2-578
093-925 Toner K Crum Data Broken Failure 2-579
093-926 Toner K Crum Data Mismatch Failure 2-579

094 BTR/IBT

094-417 BTR Unit Pre Warning RAP 2-581
094-420 BTR Unit Warning RAP 2-581

102 User Interface

102-356 Controller Software RAP 2-583
102-380 UI Control RAP 2-583
102-381 UI Data Link RAP 2-584
102-382 Application Layer Command RAP 2-584

112 Punch

112-700 Punch Dust Near Full RAP 2-585

116 Printing Control

116-210 MediaReader Fatal Error RAP 2-587
116-212 MediaL b SW Logic Fail RAP 2-587
116-220 Downloader Initialize Fail RAP 2-588
116-310 ESS Font DIMM #2 RAP 2-588
116-311 ESS Font DIMM #3 RAP 2-589
116-312 HDD Encrypt Key RAP 2-589
116-313 HDD Encrypt Setup RAP 2-590
116-314 Ethernet Address RAP 2-590
116-315 ESS DDR DIMM #1 R/W Check RAP 2-591
116-316 ESS DDR DIMM #2 R/W Check RAP 2-591
116-317 ESS ROM DIMM #1 Check RAP 2-592
116-318 ESS ROM DIMM #2 Check RAP 2-592
116-319 Controller UI Configuration 2-593
116-321 System Software RAP 2-593

service-repairmanual.com

116-322 WebDAV S/W Fail RAP 2-594
116-323 ESS NVRAM R/W Check RAP 2-594
116-324 System Controller RAP 2-595
116-325 ESS Fan RAP 2-595
116-328 Controller Cache RAP 2-596
116-329 Serial Software RAP 2-596
116-330 HDD File System RAP 2-597
116-331 Invalid Log Information RAP 2-597
116-332 ESS ROM RAP 2-598
116-333 LocalTalk Software RAP 2-598
116-334 ESS NVRAM Data Compare Fail RAP 2-599
116-335 HDD RAP 2-599
116-336 HDD Access RAP 2-600
116-337 SNTP Software RAP 2-600
116-338 JBA RAP 2-601
116-340 Memory RAP 2-601
116-341 ROM Version RAP 2-602
116-342 Network Manager RAP 2-602
116-343 Main PWB IC RAP 2-603
116-346 Formatter RAP 2-603
116-348 Redirector RAP 2-604
116-349 SIF RAP 2-604
116-350 AppleTalk Software RAP 2-605
116-351 Ether Talk Software RAP 2-605
116-352 NetWare Software RAP 2-606
116-353 HDD Mechanical RAP 2-606
116-354 HDD Product RAP 2-607
116-355 Agent Software RAP 2-607
116-356 HDD Format RAP 2-608
116-357 PostScript RAP 2-608
116-358 Salutation Software RAP 2-609
116-360 SMB Software RAP 2-609
116-361 Spool HDD RAP 2-610
116-362 SSDP Software RAP 2-610
116-363 Print Service Software RAP 2-611
116-364 Timer RAP 2-611
116-365 Spool RAP 2-612
116-366 Software Report RAP 2-612
116-367 Parallel Software RAP 2-613
116-368 Dump Print RAP 2-613
116-370 XJCL RAP 2-614
116-371 PCL Decomposer Software RAP 2-614
116-372 Formatter RAP 2-615
116-373 Dynamic DNS Software RAP 2-615
116-374 Auto Switch RAP 2-616
116-375 Formatter RAP 2-616
116-376 Port 9100 Software RAP 2-617
116-377 Video DMA RAP 2-617
116-378 Controller Software RAP 2-618
116-379 Controller Software RAP 2-618
116-380 ESS Font ROM DIMM #1 RAP 2-619
116-381 ABL Initialize RAP 2-619
116-382 ABL Initialize RAP 2-620
116-385 IDC Software RAP 2-620
116-388 MCC RAP 2-621
116-389 RAM Install RAP 2-621
116-390 ROM NVM Mismatch RAP 2-622
116-391 Country Code RAP 2-622
116-395 USB Software RAP 2-623
116-399 Initialization RAP 2-623
116-701 Memory Duplex RAP 2-624
116-702 Substitute Font RAP 2-624
116-703 PostScript Language RAP 2-625
116-710 HP-GL/2 Memory Overflow RAP 2-625
116-713 HDD Job Full RAP 2-626
116-714 HP-GL/2 Command RAP 2-626
116-720 PCL Memory RAP 2-627
116-738 Overlay Size Orientation RAP 2-627
116-739 Form/Logo Capacity RAP 2-628
116-740 Arithmetic RAP 2-628
116-741 Maximum Forms Data Register RAP 2-629
116-742 Max Logo Registered RAP 2-629
116-743 Form/Logo Size Overflow RAP 2-630
116-746 Selected Form RAP 2-630
116-747 Invalid Page Margin RAP 2-631
116-748 Page Image Data RAP 2-631
116-749 PostScript Font RAP 2-632
116-750 Banner Sheet Cancelled RAP 2-632
116-752 Print Job Ticket Description Warning RAP 2-633
116-771 Invalid JBIG Parameter DL Fixed RAP 2-633
116-772 Invalid JBIG Parameter D Fixed RAP 2-634
116-773 Invalid JBIG Parameter P Fixed RAP 2-634
116-774 Invalid JBIG Parameter YD Fixed RAP 2-635
116-775 Invalid JBIG Parameter L0 Fixed RAP 2-635
116-776 Invalid JBIG Parameter MX Fixed RAP 2-636
116-777 Invalid JBIG Parameter MY Fixed RAP 2-636
116-778 Invalid JBIG Par VLength Fixed RAP 2-637
116-780 Attached Document RAP 2-637
116-790 Stapling Canceled RAP (A-Finisher) 2-638
116-790 Stapling Canceled RAP (SB-Finisher) 2-638

121 FID-EP

121-314 Customize User Prompts Fail RAP 2-639

123 Controller-UI

123-207 Communication Manager Target RAP 2-641
123-209 Controller UI Communication RAP 2-641
123-310 Send Queue RAP 2-642
123-311 Receive Queue RAP 2-642
123-317 Receive Message Queue RAP 2-643
123-318 Receive Finish Queue RAP 2-643
123-320 NVM Initialized for FCW Composition RAP 2-644
123-322 UI Target RAP 2-644
123-323 UI Address RAP 2-645

service repair manuals.com

123-325 Object Creation RAP 2-645
123-326 Memory Overflow RAP 2-646
123-327 Button Overflow RAP 2-646
123-328 UI Internal Range RAP 2-647
123-329 UI Coordinates RAP 2-647
123-332 Interface Parameter RAP 2-648
123-333 Interface Communication RAP 2-648
123-337 Frame Data RAP 2-649
123-341 Event Queue RAP 2-649
123-342 Event Queue RAP 2-650
123-343 Invalid Class RAP 2-650
123-344 Invalid Type RAP 2-651
123-345 Timer Queue Full RAP 2-651
123-346 Invalid Timer Number RAP 2-652
123-369 Interface Value RAP 2-652
123-370 Interface Length RAP 2-653
123-371 Interface Parameter RAP 2-653
123-372 Interface Sequence RAP 2-654
123-373 Channel RAP 2-654
123-374 User Job ID RAP 2-655
123-375 Internal Resource RAP 2-655
123-376 Internal Memory RAP 2-656
123-377 UI Timer RAP 2-656
123-378 Interface Format RAP 2-657
123-379 Dispatch RAP 2-657
123-380 Copy Interface RAP 2-658
123-381 Fax Interface RAP 2-658
123-382 Scanner Interface RAP 2-659
123-383 Report Interface RAP 2-659
123-384 Server Access RAP 2-660
123-385 Service Object RAP 2-660
123-386 Service Object RAP 2-661
123-387 Service Object RAP 2-661
123-388 Attribute RAP 2-662
123-389 UI Comparator RAP 2-662
123-390 Job Parameter RAP 2-663
123-391 Job Parameter RAP 2-663
123-392 Auditron RAP 2-664
123-394 File Access RAP 2-664
123-395 UI NVM RAP 2-665
123-396 UI Software RAP 2-665
123-397 UI Manager RAP 2-666
123-398 Release Queue RAP 2-666
123-399 UI Internal RAP 2-667
123-400 Internal Interface RAP 2-667

124 ROM-RAM

124-310 Product Designation RAP 2-669
124-311 Product Serial Number RAP 2-669
124-312 Machine Codes Mismatch RAP 2-670
124-313 Serial Number RAP 2-670
124-314 IOT Speed RAP 2-671
124-315 Serial Number Mismatch RAP 2-671
124-316 Product Mode RAP 2-672
124-317 All Product Mode RAP 2-672
124-318 Product Type Software Key RAP 2-673
124-319 All Product Types Software Key RAP 2-673
124-320 EPROM RAP 2-674
124-321 Backup SRAM RAP 2-674
124-322 Software Key RAP 2-675
124-323 Software Key Registration RAP 2-675
124-324 All Billings Mismatch RAP 2-676
124-325 Billing Restoration RAP 2-676
124-326 IOT Speed Not Registered RAP 2-677
124-327 IOT Speed Change SW Failure RAP 2-677
124-333 ASIC RAP 2-678
124-334 Standard Font ROM RAP 2-678
124-335 Font ROM RAP 2-679
124-337 ESS Standard RAM RAP 2-679
124-338 Duplicate Font ROMs RAP 2-680
124-339 ROM DIMM Mismatch RAP 2-680
124-340 CRUM Market RAP 2-681
124-341 CRUM Market MCU RAP 2-681
124-342 CRUM Market System 1 RAP 2-682
124-343 CRUM Market System 2 RAP 2-682
124-350 CRUM OEM RAP 2-683
124-351 CRUM OEM MCU RAP 2-683
124-352 CRUM OEM System 1 RAP 2-684
124-353 CRUM OEM System 2 RAP 2-684
124-360 CRUM Validation RAP 2-685
124-361 CRUM Validation MCU RAP 2-685
124-362 CRUM Validation System 1 RAP 2-686
124-363 CRUM validation System 2 RAP 2-686
124-372 IOT Controller Software RAP 2-687
124-373 IOT Manager Software RAP 2-687
124-374 IOT IM Device Driver Software RAP 2-688
124-380 CRUM Market (2) 2-688
124-381 CRUM Market MCU (2) 2-689
124-382 CRUM Market System 1 (2) 2-689
124-383 CRUM Market System 2 (2) 2-690
124-390 OEM Market (2) 2-690
124-391 CRU OEM MCU (2) 2-691
124-392 CRU OEM System 1 (2) 2-691
124-393 CRU OEM System 2 (2) 2-692
124-701 Side Tray to Center Tray RAP 2-692
124-702 Finisher Tray to Center Tray RAP 2-693
124-705 Punching Cancelled RAP 2-693
124-706 Folding Cancelled RAP 2-694
124-708 Output Tray Changed to Sub Tray RAP 2-694
124-709 Side Tray to Center Tray RAP 2-695
124-710 Output Tray Changed from MailBoxSorter RAP 2-695

125 PWScont

125-311 PSW Unexpected Fail RAP 2-697

www.freerepairmanual.com

127 Software

127-310 ESR Task RAP 2-699
127-314 WSD Print S/W Fail RAP 2-699
127-353 LPD Software RAP 2-700
127-396 Mail I/O Software RAP 2-700
127-398 IPP Software RAP 2-701
127-399 JME Software RAP 2-701

133 Fax Control

133-210 Fax Parameter RAP 2-703
133-211 Fax Parameter Value Invalid RAP 2-703
133-212 Fax Read Error- No Data RAP 2-704
133-213 Fax Read Error- Invalid Data RAP 2-704
133-214 Fax USB Initializing RAP 2-705
133-215 Fax USB Device RAP 2-705
133-216 Fax USB Host Fatal RAP 2-706
133-217 Fax Manager Short of Memory RAP 2-706
133-218 Fax Card Message L brary Short of Memory RAP 2-707
133-219 Fax Work Memory RAP 2-707
133-220 Fax Control Task RAP 2-708
133-221 Fax Card Boot RAP 2-708
133-222 Fax Card does not respond intervalley RAP 2-709
133-223 Fax Card Reset RAP 2-709
133-224 Controller ROM Fax Card ROM RAP 2-710
133-226 Country Code RAP 2-710
133-280 Fax Option Slot 1 Board RAP 2-711
133-281 Received unknown message RAP 2-711
133-282 Fax Card Download RAP 2-712
133-283 Fax Report Mailbox RAP 2-712
133-700 Staple/Punch Cancelled RAP 2-713
133-710 Tray Select Fail RAP 2-713

134 Fax Card

134-210 Fax Controller Parameter RAP 2-715
134-211 FAX PWB RAP 2-715

202 Timer

202-399 Internal Timer RAP 2-717

Other Faults

OF 1 Paper Size Mismatch In Width RAP 2-719
OF 2 Size Switch Assy RAP 2-719
OF 3 Main Drive Assy RAP 2-721
OF 4 Dark / Blank Display RAP 2-721

service-repairmanuals.com

3 Image Quality

Image Quality RAPs

IQ1 IOT Image Quality Entry RAP 3-3
IQ2 IIT Image Quality Entry RAP 3-3
IQ3 Low Image Density RAP 3-4
IQ4 Wrinkled Image RAP 3-4
IQ5 Residual Image (Ghosting) RAP 3-5
IQ6 Background RAP 3-5
IQ7 Deletion RAP 3-6
IQ8 Skew/Misregistration RAP 3-6
IQ9 Process Direction Bands, Streaks and Smears RAP 3-7
IQ10 Unfused Copy/Toner Offset RAP 3-8
IQ11 Repeating Bands, Streaks, Spots and Smears RAP 3-8
IQ12 Mottle RAP 3-9
IQ13 Spots RAP 3-9
IQ14 Black Prints RAP 3-10
IQ15 Blank Image RAP 3-10

Copy Quality Specifications

Copy Quality Specifications 3-11
IQS1 Solid Area Density Specification 3-13
IQS2 Uniformity Specification 3-13
IQS3 Exposure Level Specification 3-14
IQS4 Lead Edge Registration Specification 3-14
IQS5 Side Edge Registration Specification 3-15
IQS6 Skew Specification 3-16
IQS7 Lead Edge Deletion Specification 3-17
IQS8 Trail Edge Deletion Specification 3-18
IQS9 Side Edge Deletion Specification 3-18
IQS10 Resolution Specification 3-19
IQS11 Skips And Smears Specification 3-20
IQS12 Magnification Specification 3-21
IQS13 Background Specification 3-22

Defect Samples

Image Defect Samples 3-23
Auger Mark 3-23
Strobing (28mm or 14mm Pitch Density) 3-24
White Streaks (Process Direction) 3-24
Black Bands 3-25
Toner Contamination 3-25
Toner Splattering 3-26
White Spots (Irregular) 3-26
Transparency Offset (80mm Pitch Ghosts) 3-27
Regular Blanks In Process Direction (Spots, Streaks, Bands etc.) 3-27
Regular Toner Contamination In Process Direction (Spots, Streaks, Bands etc.) 3-28
Regular Toner Contamination In Process Direction (Side 2) 3-29
Transparency Blocking 3-29
Moire Due To Interference With Copy Original 3-30
Light Background Due To Auto Exposure In Copies Of Originals With Frames 3-30
Fluctuation In Auto Exposure Values For Copies Of Originals Of Medium Density 3-31
Gradation Jump In Text & Photo Mode For 100 lpi Photo Originals 3-31
CVT (Constant Velocity Transport) Scan Streaks 3-32
Defects Related To Scan Print 3-32
Moire In Text Mode (Fine) B/W Scan/Fax For 133 lpi Originals 3-33
Black Discoloration Around White Texts In Medium Density Background 3-33

service-repairmanual.com

4 Repairs and Adjustments

01. Drives
REP 1.1.1 Main Drive Assembly 4-3

02. Paper Transportation
REP 2.1.1 Feeder 1 Assembly 4-7
REP 2.1.2 Feeder 2 Assembly 4-9
REP 2.3.1 Tray Feed/Nudger/Retard Roll 4-10
REP 2.4.1 Registration Unit 4-12
REP 2.5.1 Takeaway Roll 4-13
REP 2.6.1 BTR Roll 4-15
REP 2.6.2 L/H Upper Cover Unit 4-16

03. ROS
REP 3.1.1 ROS Unit 4-19

04. Xerographic/Development
REP 4.1.1 Xero/Developer Cartridge 4-23
REP 4.1.2 Toner Cartridge 4-24
REP 4.2.1 Dispense Motor 4-25

05. Fuser
REP 5.1.1 Fuser Unit 4-29

06. Exit
REP 6.1.1 Exit2 + OCT2 4-31

07. HCF
REP 7.1.1 MPT Assembly 4-33
REP 7.2.1 MPT Feed Roll/Retard Pad 4-34
REP 7.3.1 HCF Tray 6 4-36
REP 7.3.2 HCF Feeder 4-37
REP 7.3.3 HCF Un-docking and Docking 4-38
REP 7.3.4 HCF Tray Cables 4-39
REP 7.3.5 HCF Retard / Feed / Nudger Rolls 4-45
REP 7.3.6 HCF Feed Shaft 4-46
REP 7.3.7 HCF Retard Lever Spring 4-46
REP 7.3.8 HCF Nudger Bracket/Nudger Lever/Torsion Spring 4-47
REP 7.3.9 HCF Casters 4-48
REP 7.3.10 HCF Takeaway Roll 4-48
REP 7.3.11 HCF PWB 4-49
REP 7.3.12 HCF Feed Motor 4-49

09. Electrical Components
REP 9.1.1 MCU PWB 4-51
REP 9.1.2 MCU PWB EPROM 4-53
REP 9.2.1 ESS PWB 4-54
REP 9.2.2 ESS PWB EPROM 4-58

10. Covers
REP 10.1.1 Top Cover Assembly 4-59
REP 10.2.1 Rear Lower Cover 4-61

11. IIT
REP 11.1.1 Platen Cushion 4-63
REP 11.1.2 Control Panel Assembly 4-64
REP 11.3.1 Platen Glass 4-64
REP 11.3.2 IIT/IPS PWB (Mono) 4-65
REP 11.3.3 IIT/IPS PWB (Color) 4-67
REP 11.4.1 Lens Kit Assembly (Mono) 4-72
REP 11.4.2 Lens Kit Assembly (Color) 4-77
REP 11.5.1 Carriage Cable 4-81
REP 11.5.2 Carriage Motor Assembly 4-86
REP 11.6.1 Exposure Lamp 4-88
REP 11.6.2 Lamp Wire Harness (Mono) 4-89
REP 11.6.3 Lamp Wire Harness (Color) 4-91

12 Tray Module - 2TM
REP 12.1 Tray 3 Feeder (2TM) 4-95
REP 12.2 Tray 4 Feeder (2TM) 4-98
REP 12.3 Feed/Retard/Nudger Roll (2TM) 4-101
REP 12.4 2TM PWB 4-102

13. TTM Tray Module
REP 13.1.1 Tray 3 Assembly (TTM) 4-103
REP 13.1.2 Tray 4 Assembly (TTM) 4-104
REP 13.3.1 Front/Rear Tray Cable (TTM) 4-105
REP 13.4.1 Tray 4 Feeder (TTM) 4-106
REP 13.5.1 Tray 3 Feeder (TTM) 4-109
REP 13.6.1 Feed/Retard/Nudger Roll (TTM) 4-111
REP 13.8.1 TTM PWB 4-112

15. DADF
REP 15.1.1 DADF 4-113
REP 15.1.2 DADF Platen Cushion 4-115
REP 15.2.1 DADF Document Tray 4-116
REP 15.2.2 DADF Feeder Assembly 4-118
REP 15.2.3 DADF Front Cover 4-120
REP 15.2.4 DADF Rear Cover 4-120
REP 15.3.1 DADF PWB 4-122
REP 15.3.2 Left Counter Balance 4-123
REP 15.3.3 Right Counter Balance 4-124
REP 15.4.1 Retard Roll 4-125
REP 15.4.2 Top Cover Assembly 4-127
REP 15.6.1 Nudger Roll, Feed Roll 4-132
REP 15.8.1 Registration Roll 4-137

16. SB Finisher
REP 16.1.1 H-Transport Assembly 4-143
REP 16.1.2 Hole Punch Assembly 4-143

Printer-Manuals.com

REP 16.1.3 H-Transport Belt 4-144
REP 16.1.4 H-Transport Motor 4-144
REP 16.2.1 SB-Finisher Undocking 4-145
REP 16.2.2 Front Cover Assembly 4-146
REP 16.2.3 Rear Upper Cover 4-147
REP 16.2.4 Rear Lower Cover 4-147
REP 16.2.5 Eject Cover 4-148
REP 16.2.6 Foot Cover 4-151
REP 16.2.7 Stacker Lower Cover 4-151
REP 16.2.8 Stacker Upper Cover 4-152
REP 16.2.9 Stack Height Sensors 1 and 2 4-152
REP 16.2.10 Sub Paddle Solenoid Assembly 4-153
REP 16.2.11 Finisher Stapler Move Motor 4-153
REP 16.2.12 Finisher Stapler Assembly 4-155
REP 16.2.13 Compiler Tray Assembly 4-156
REP 16.2.14 Folder Knife Assembly 4-166
REP 16.2.15 Stacker Elevator Motor 4-167
REP 16.2.16 Stacker Tray 4-167
REP 16.2.18 Eject Belt 4-168
REP 16.2.19 Eject Motor Assembly 4-168
REP 16.2.21 Finisher PWB 4-169
REP 16.2.22 Finisher LVPS 4-169
REP 16.2.23 Eject Motor 4-170
REP 16.2.24 Front/Rear Tamper Motor 4-170
REP 16.2.25 Front/Rear Tamper Home Sensors 4-171
REP 16.2.26 Compiler No Paper Sensor 4-171
REP 16.2.27 Front/Rear Carriage Assembly 4-172
REP 16.3.1 Booklet PWB 4-173
REP 16.3.2 Booklet Maker Assembly 4-174
REP 16.3.3 Booklet Front Cover 4-176
REP 16.3.4 Booklet Rear Cover 4-177
REP 16.3.5 Booklet Top Cover 4-179
REP 16.3.6 Booklet PWB Cover 4-179
REP 16.3.7 Booklet Left Cover 4-180
REP 16.3.8 Booklet Front/Rear Stapler 4-180
REP 16.3.9 Booklet Stapler Move Motor 4-182

22. A Finisher

REP 22.1 Intergrated Office Finisher 4-185
REP 22.3.1 Paddle Belt 4-187
REP 22.3.2 Sub Paddle Solenoid 4-189
REP 22.4.1 Exit Roll Assembly 4-191
REP 22.4.2 Staple Assembly 4-193
REP 22.4.3 Set Clamp Home Sensor 4-194
REP 22.4.4 Exit Roll Assembly 4-196
REP 22.5.1 Pinch Roll 4-198
REP 22.5.2 Finisher Entrance Sensor 4-198
REP 22.5.3 Compile Exit Sensor 4-200
REP 22.5.4 Main Paddle Shaft Assembly 4-201
REP 22.5.5 Lower Chute Assembly 4-203
REP 22.6.1 ENT Roll Assembly 4-206
REP 22.6.2 Upper Chute Assembly 4-208
REP 22.7.1 Finisher Control PWB 4-209
REP 22.8.1 Stacker Tray Assembly 4-210
REP 22.8.2 Stacker Shaft Assembly 4-211
REP 22.8.3 Stacker Motor 4-214
REP 22.8.4 Stacker Stack Sensor 4-216
REP 22.9.1 Compile Assembly 4-216
REP 22.9.2 Set Clamp Shaft 4-218
REP 22.9.3 Eject Belts 4-220
REP 22.9.4 Eject/Set Clamp Motor Assembly 4-221
REP 22.9.5 Rear Tamper Home Sensor 4-223
REP 22.9.6 Eject Shaft Assembly 4-225
REP 22.10.1 Front/Rear Tamper Motor Assembly 4-226
REP 22.10.2 Front Tamper Home Sensor 4-228
REP 22.10.3 Eject Clamp Home Sensor 4-229
REP 22.10.4 Stack Height Sensor 4-231

7. HCF

ADJ 7.1.2 HCF Side Edge Registration 4-233

9. Electrical Components

ADJ 9.1.1 IOT Lead Edge/Side Edge Registration 4-235
ADJ 9.2.1 Edge Erase Value Adjustment 4-237
ADJ 9.3.1 Firmware Version Downloading 4-238

11. IIT

ADJ 11.1.1 IIT Lead Edge/Side Edge Registration 4-239
ADJ 11.2.1 Reduce/Enlarge Adjustment 4-240
ADJ 11.6.1 Full/Half Rate Carriage Position Adjustment 4-241

15. DADF

ADJ 15.1.1 DADF Side Edge Registration 4-245
ADJ 15.1.3 DADF Non-Standard Sized Original Customized Registration Function 4-246
ADJ 15.1.4 DADF Lead Edge Registration 4-247
ADJ 15.1.5 DADF Height Adjustment 4-249
ADJ 15.1.6 DADF Position (Skew) Adjustment 4-250

service-repairmanual.com

5 Parts List

Overview

Introduction 5-3
Subsystem Information 5-4
Symbology 5-5

Parts Lists

1. Drives

PL 1.1 Main Drive 5-7

2. Paper Transportation

PL 2.1 Tray, Feeder 1/2 Assembly 5-8
PL 2.2 Tray 1/2 5-9
PL 2.3 Feeder 1/2 Assembly 5-10
PL 2.4 Registration 5-11
PL 2.5 Vertical Transport Cover 5-12
PL 2.6 Transfer Cover Assembly 5-13
PL 2.7 L/H Upper Chute Assembly 5-14
PL 2.8 L/H Upper Cover Assembly 5-15
PL 2.9 Envelope Tray Assembly 5-16

3. ROS

PL 3.1 ROS 5-17

4. Xerographics/Develoment

PL 4.1 CRU, Toner Cartridge 5-18
PL 4.2 Toner System 5-19

5. Fuser

PL 5.1 Fuser Unit 5-20

6. Exit

PL 6.1 Exit 5-21
PL 6.2 Exit 1 5-22
PL 6.3 L/H Upper Chute Assembly 5-23
PL 6.4 Tray Guide Assembly 5-24
PL 6.5 Tray Guide Assembly 5-25

7. MSI

PL 7.1 MSI Assembly 5-26
PL 7.2 Lower Frame Assembly 5-27
PL 7.3 MSI Tray Assembly 5-28

8. Duplex

PL 8.1 Duplex Unit 5-29
PL 8.2 Inner Chute Assembly 5-30

9. Electrical Components

PL 9.1 Electrical 5-31
PL 9.2 ESS 5-32
PL 9.3 FAX Unit 5-33
PL 9.4 Wire Harnesses 5-34

10. Covers

PL 10.1 Cover-Front, Left 5-35
PL 10.2 Cover-Rear, Right 5-36

11. IIT

PL 11.1 Platen/Cover 5-37
PL 11.2 Control Panel 5-38
PL 11.3 Platen Glass 5-39
PL 11.4 CCD PWB, Sensor 5-40
PL 11.5 Carriage Cable/Motor 5-41
PL 11.6 Full/Half Rate Carriage 5-42

12. Tray Module-2T

PL 12.1 Tray, Feeder Assembly-2 Tray 5-43
PL 12.2 Tray 3/4 Assembly-2 Tray 5-44
PL 12.3 Tray 3/4 Feeder- 2 Tray 5-45
PL 12.4 Left Cover-2 Tray 5-46
PL 12.5 Takeaway Roll-2 Tray 5-47
PL 12.6 Electrical-2 Tray 5-48
PL 12.7 Cover-2 Tray 5-49

13. Tray Module-TT

PL 13.1 Tray 3/4 Assembly-Tandem 5-50
PL 13.2 Tray 3 Assembly-Tandem 5-51
PL 13.3 Tray 4 Assembly-Tandem 5-52
PL 13.4 Paper Feed (1/2)-Tandem 5-53
PL 13.5 Paper Feed (2/2)-Tandem 5-54
PL 13.6 Tray 3/4 Feeder-Tandem Tray 5-55
PL 13.7 Left Cover Assembly-Tandem 5-56
PL 13.8 Electrical-Tandem Tray 5-57
PL 13.9 Cover-Tandem Tray 5-58

14. Mobile Stand

PL 14.1 Mobile Stand 5-59

15. DADF

PL 15.1 DADF 5-60
PL 15.2 DADF Component Cover 5-61
PL 15.3 DADF Base Cover 5-62
PL 15.4 DADF Feeder Component 5-63
PL 15.5 Top Cover Component 5-64
PL 15.6 Takeaway Pinch Roll, Nudger Motor, Nudger/Feed Roll 5-65
PL 15.7 DADF Feeder-Chute 5-66
PL 15.8 DADF Feeder-Roll 5-67
PL 15.9 Motor Unit Assembly 5-68
PL 15.10 DADF Document Tray 5-69

service-repairmanuals.net

18. HCF

PL 18.1 HCF Unit 5-70
PL 18.2 HCF Tray 6 (1 of 2) 5-71
PL 18.3 HCF Tray 6 (2 of 2) 5-72
PL 18.4 HCF Feeder (1 of 3) 5-73
PL 18.5 HCF Feeder (2 of 3) 5-74
PL 18.6 HCF Feeder (3 of 3) 5-75
PL 18.7 HCF Top Cover Unit 5-76
PL 18.8 HCF Electrical and Rail 5-77

22. Integrated Office Finisher

PL 22.1 Finisher Assembly (Part 1 of 2) (Integrated Office Finisher) 5-78
PL 22.2 Finisher Assembly (Part 2 of 2) (Integrated Office Finisher) 5-79
PL 22.3 Stacker Base Assembly (Part 1 of 5) (Integrated Office Finisher) 5-80
PL 22.4 Stacker Base Assembly (Part 2 of 5) (Integrated Office Finisher) 5-81
PL 22.5 Stacker Base Assembly (Part 3 of 5) (Integrated Office Finisher) 5-82
PL 22.6 Stacker Base Assembly (Part 4 of 5) (Integrated Office Finisher) 5-83
PL 22.7 Stacker Base Assembly (Part 5 of 5) (Integrated Office Finisher) 5-84
PL 22.8 Stacker Tray Assembly (Integrated Office Finisher) 5-85
PL 22.9 Compile Assembly (Part 1 of 2) (Integrated Office Finisher) 5-86
PL 22.10 Compile Assembly (Part 2 of 2) (Integrated Office Finisher) 5-87

23. Office Finisher LX

PL 23.1 H-Transport Assembly (1 of 5) (Office Finisher LX) 5-88
PL 23.2 H - Transport Assembly (2 of 5) (Office Finisher LX) 5-89
PL 23.3 H - Transport Assembly (3 of 5) (Office Finisher LX) 5-90
PL 23.4 H - Transport Assembly (4 of 5) (Office Finisher LX) 5-91
PL 23.5 H - Transport Assembly (5 of 5) (Office Finisher LX) 5-92
PL 23.6 Finisher Covers (Office Finisher LX) 5-93
PL 23.7 Finisher Stacker (Office Finisher LX) 5-94
PL 23.8 Finisher Stapler (Office Finisher LX) 5-95
PL 23.9 Finisher Eject (1 of 5) (Office Finisher LX) 5-96
PL 23.10 Finisher Eject (2 of 5) (Office Finisher LX) 5-97
PL 23.11 Finisher Eject (3 of 5) (Office Finisher LX) 5-98
PL 23.12 Finisher Eject (4 of 5) (Office Finisher LX) 5-99
PL 23.13 Finisher Eject (5 of 5) (Office Finisher LX) 5-100
PL 23.14 Finisher Exit/Folder Assembly (Office Finisher LX) 5-101
PL 23.15 Folder Assembly (Office Finisher LX) 5-102
PL 23.16 Finisher Electrical (Office Finisher LX) 5-103
PL 23.17 Booklet Cover (Office Finisher LX) 5-104
PL 23.18 Booklet Stapler Assembly (Office Finisher LX) 5-105
PL 23.19 Booklet Front Stapler Assembly (Office Finisher LX) 5-106
PL 23.20 Booklet Rear Stapler Assembly (Office Finisher LX) 5-107
PL 23.21 Booklet Electrical (Office Finisher LX) 5-108

Common Hardware

Common Hardware 5-109
Part Number Index 5-110

service-repairmanual.com

6 General Procedures and Information

How to use UI Diagnostics

UI Diagnostic Mode 6-3

Various Reports

Jam Report 6-5
Failure Report 6-5
Shutdown Report 6-6

Diagnostics (NVM)

NVM Read/Write 6-7
IOT NVM List 6-8
IIT NVM List 6-31
Controller & Fax NVM List 6-44

Diagnostics (Others)

Serial Number/Billing Meter Data 6-115
Reading HFSI 6-116
Initialize HFSI Counters 6-117
Adjust Tone Up / Down 6-121
Tray5 (Bypass) Guide Adjustment 6-122
Initialize NVM 6-123
Component Control 6-125
Hard Disk Diagnostic Program 6-136
Test Pattern Print 6-137
Webpage Administrator Password 6-139
Center Tray Offsetting 6-140
E-Mail Icon 6-140
FAX Output Separation 6-141

General Procedures

GP 1 Intermittent Problem RAP 6-143
GP 2 Fax Diagnostics 6-144
GP 3 Resetting the Administrator Password 6-146
GP 4 Replacing Billing PWBs 6-147
GP 5 Printing Reports 6-148
GP 6 Special Boot Modes 6-149
GP 7 Country Code Setting 6-150
GP 8 Firmware Version 6-151
GP 9 Key Operator Log In 6-152

General Information

Space Requirements 6-153
Product Specs. 6-154
Common Tools 6-156
Product Tools and Test Patterns 6-157
Log Book Storage 6-157
Cleaning Materials 6-158
Machine Consumables 6-158
Glossary of Terms 6-159

Change Tag Information

Change Tag Introduction 6-161
IOT/Processor (P) Tags 6-161

service-repairmanual.com

7 Wiring Data

7 Plug/Jack Locations Integrated Finisher

7.1.1 Plug/Jack Locations Integrated Finisher 7-3
7.1.2 Plug/Jack Illustrations 7-4

7 LX Finisher Plug/Jack Locations

LX Finisher Plug/Jack Locations 7-7

7 HCF Plug/Jack Locations

HCF Plug/Jack Locations 7-15

7 Plug/Jack Locations

Plug/Jack Locations 7-17

7 Wirenets

IOT Wirenets 7-45
HCF Wirenets 7-60
Integrated Office Finisher Wirenets 7-63
Office Finisher LX Wirenets 7-66

7 BSDs

Chain 1 Standby Power 7-69
Chain 2 User Interface 7-73
Chain 3 Machine Run Control 7-77
Chain 4 Start Print Power 7-87
Chain 5 Document Transportation 7-88
Chain 6 Imaging 7-94
Chain 7 Paper Supply 7-101
Chain 8 Paper Feed and Transportation 7-116
Chain 9 Xerographics 7-125
Chain 10 Copy Transportation and Fusing 7-129
Chain 12 Finishing 7-136
Chain 16 ESS 7-162
Chain 17 FAX 7-163

service-repairmanual.com